



SAVING TCU800 SETTINGS TO USB

1 Is the unit currently powered on?

No:

Continue to step 2. Yes: Skip to step 3. I don't know: Tap the screen once or twice and wait a second. If the display comes on, then the unit is powered up.

2 Remove the existing TCU800 Configuration USB (if present).

Power on the TCU800 by pressing the home button and wait until the unit has reached the main home screen.

STAT E RX E TX E Data Flow Systems

Quick View

OFF

≣

3 Tap the hamburger menu ≡ in the top left of the screen.

If you do not see the \equiv icon, tap anywhere on the screen once and it will appear.

4 Tap *Advanced*.



ow Off Lead Lag Lag2 Hig

5 Tap *Device Manager*.



5 Tap Save Configuration to USB.



6 Wait for the prompt to say "Export Successful," then tap **Ok**.

If a message indicating "No USB detected" is displayed, then there may be a problem with your USB flash drive. It should be removed and replaced.

Deulee Menseen	
Message Prompt	
Export successful	
Ok	

7 Is this configuration USB drive going to be left in the unit during normal operation?

Yes:

Press the Home button to return to the main screen.

No:

Follow procedure *TCUOP0100:* SAFLEY REMOVING USB FROM A *TCU800*